


Dronix DR1200 ICD

Ver 1.0122



This document is the property of Dronix engineering Ltd reserves its rights document and to the data/invention/content herein described. This document, including the fact of its existence, is not to be disclosed, in whole or in part, to any other party and it shall not be duplicated, used, or copied in any form, without the express prior written permission of Dronix authorized person.

Acceptance of this document will be construed as acceptance of the foregoing conditions.

Mail: Ravnitski St 6, zip code: 4900617 T: 972-3-7778746



Compilation and Publication Notice

Compilation and Publication Notice This manual is covering the latest product descriptions and specifications. It is our policy to constantly improve the design and specifications. Accordingly, the details represented herein cannot be regarded as final and binding. The contents of this manual and the specifications of this product are subject to change without notice. Dronix engineering reserves the right to make changes without notice in the specifications and materials contained herein and shall not be responsible for any damages (including consequential) caused by reliance on the materials presented, including but not limited to typographical and other errors relating to the publication. For further information please contact Dronix engineering ltd.

For further information, please contact us at info@dronix.co.il

Mail: Ravnitski St 6, zip code: 4900617 T: 972-3-7778746



Table Of Contents

1.	INTRODUCTION	.4
2.	Mechanical interfaces	.4-5
3.	Electrical interfaces	6
4.	Revision Control	7

Mail: Ravnitski St 6, zip code: 4900617 T: 972-3-7778746

1. Introduction

This document describes the mechanical and electrical ICD and Interconnect for the Dronix DR1200 platform.

2. Mechanical interfaces

- 2.1. To simplify the external interface to the payloads the DR1200 has a double carbon tube rales with a shock-absorbing damper system.
- 2.2. the shock-absorbing system allows customers to simplify the payload integration.
- 2.3. Dronix Customized payloads plate can be integrated easily into the mechanical interface of the drone




Figure 2.1: DR1200 front mechanical interfaces scheme

Mail: Ravnitski St 6, zip code: 4900617 T: 972-3-7778746






Figure 2.1: DR1200 bottom mechanical interfaces scheme




Figure 2.3: DR1200 Customized payloads plate mechanical interfaces scheme

Mail: Ravnitski St 6, zip code: 4900617 T: 972-3-7778746



3. Electrical interfaces

- 3.1. The Dronix DR1200 system has an external power and data board for 3rd party system components.
- 3.2. The external board is an accessory supplied by Dronix to allows customers to simplify the payload integration and quick power-up




Figure 3: DR1200 external power and data board interfaces scheme

Pin	Output	Туре	Description
1	XT30 Female – 5V 5A	Power	Power output for
			camera/computer/communication/other
2	XT30 Female – 12V	Power	Power output for
	5A #1		camera/computer/communication/other
3	XT30 Female – 12V	Power	Power output for
	5A #2		camera/computer/communication/other
4	XT60 Female – 24V	Power	Power output for
	3A		camera/computer/communication/other
5	5.5 x 2.1 mm female	Power	Power output for
	DC Power Connector		camera/computer/communication/other
6	I2C Port	Data	Flight controller I2C port
7	TELEM1 Port	Data	Flight controller TELEM1 port
8	TELEM2 Port	Data	Flight controller TELEM2 port
9	AUX S1	Data	Flight controller PWM port
10	AUX S2	Data	Flight controller PWM port
11	AUX S3	Data	Flight controller PWM port

Mail: Ravnitski St 6, zip code: 4900617 T: 972-3-7778746





Attention – power and data connectors MUST be connected properly. Poor

connections can cause system malfunction and may cause damage.

Revision Control

Version	Description
1.0	Created
1.0122	External power and data board

Mail: Ravnitski St 6, zip code: 4900617 T: 972-3-7778746